

Laptops with Built in Fingerprint sensors

Most laptop manufacturers do not release the manufacturer or type of sensor embedded on their laptops. This information is from several sources and may not be 100% accurate.

Key

123ID Supported Sensor

Unsure of Model but Manufacturer is supported or appears to be a supported sensor

Not Supported by 123ID at this time

Unknown

| Dell | Sensor Notes |
|-----------------------|---|
| New Models | |
| Vostro 1320 | sweep sensor from UPEK |
| Vostro 1720 | sweep sensor from UPEK |
| Vostro 1520 | sweep sensor from UPEK |
| Vostro 1510 | sweep sensor from UPEK |
| Vostro 1710 | sweep sensor from UPEK |
| Latitude E4200 | Authentec 2810 Swipe Sensor |
| Latitude E4300 | Authentec 2810 Swipe Sensor |
| Latitude E6500 | Authentec 2810 Swipe Sensor |
| Latitude E6400 | Authentec 2810 Swipe Sensor |
| Latitude E6400 ATG | Authentec 2810 Swipe Sensor |
| Latitude E5400 | Authentec 2810 Swipe Sensor |
| Latitude E5500 | Authentec 2810 Swipe Sensor |
| Precision M4400 | Fingerprint Reader OR FIPS Fingerprint Reader |
| Precision M2400 | Fingerprint Reader (optional) |
| Precision M6400 Covet | Fingerprint Reader (optional) |
| Precision M6400 | Fingerprint Reader (optional) |
| 2006 | |
| D620 | sweep sensor from upek |
| D820 | sweep sensor from upek |
| Latitude TM D420 | sweep sensor from upek |
| Precision M65 | sweep sensor from upek |
| 2007 | |
| D430 | sweep sensor from upek |
| D830 | sweep sensor from upek |
| D630 | sweep sensor from upek |
| Precision M4300 | sweep sensor from upek |
| XPSm 1330 | sweep sensor from upek |
| XPSm 1530 | sweep sensor from upek |
| M6300 | sweep sensor from upek |
| Vostro 1200 | sweep sensor from upek |

| | |
|------------------------|---|
| M2300 | sweep sensor from upek |
| 2008 | |
| Vostro 1310 | sweep sensor from UPEK |
| Vostro 1510 | sweep sensor from UPEK |
| Vostro 1710 | sweep sensor from UPEK |
| Latituce XFR D630 | sweep sensor from Authentec |
| E4200 | sweep sensor from Authentec |
| E4300 | sweep sensor from Authentec |
| Studio 17 | optional swipe sensor |
| Studio 15 | optional swipe sensor |
| E6400 | sweep sensor from Authentec |
| E6500 | optional UPEK area sensor or swipe sensor |
| E5400 | optional UPEK area sensor or Authentec swipe sensor |
| E5500 | optional swipe sensor |
| M4400 | Optional UPEK TouchChip or swipe sensor |
| M6400 | Optional UPEK TouchChip or Authentec swipe sensor |
| E6400 XFR | Upek swipe sensor |
| HP | Sensor Notes |
| New Models | |
| B series | HP Fingerprint reader |
| P Series | HP Fingerprint reader |
| W series | HP Fingerprint reader |
| dv3 series | Authentec Swipe Sensor |
| 2005 | |
| nx6125 | AES 2501 |
| nx6325 | AES 2501 |
| 2006 | |
| nx6320 | AES 2501 |
| nx6330 | AES 2501 |
| nc6320 | AES 2501 |
| nx9420 and nw9440 | AES 2501 |
| nw8440 | AES 2501 |
| nc2400 and nc6400 | AES 2501 |
| nc4400 and tc4400 | AES 2501 |
| tx1000z | AES 1610 |
| 2007 | |
| tx1110us touch screen | AES 1610 |
| tx1020ea | AES 1610 |
| tx1310au | AES 1610 |
| tx2000 | AES 1610 |
| tx2500 | AES 1610 |
| Compaq 8710w and 8710p | AES 2501 |
| 8730W | AES 2501 |
| Compaq 6515b & 6715b | AES 2501 |
| Compaq 8510w, 8510p | AES 2501 |
| Compaq 6910p, 2510p | AES 2501 |
| Compaq 6510b, 6710b | AES 2501 |

| | |
|------------------------------------|--|
| Compaq 6710p | AES 2501 |
| 8530W | AES 2501 |
| Pavilion dv2500t, dv6500t, dv9500t | AES 2501 |
| dv2530 and dv2622 | AES 2501 |
| dv2621 | AES 2501 |
| 2710 Tablet PC | AES 2501 |
| Pavilion HDX | AES 2501 |
| Compaq 2210b | AES 2501 |
| Compaq 6530b/6730b | AES 2501 |
| 2008 | |
| dv2727, dv9700, dv6700 | AES 2501 |
| dv2699, dv2803 | AES 2501 |
| dv2905 | AES 2501 |
| 2730p | AES 2501 |
| Pavilion dv3000 | Validity Sensor |
| dv4, dv5, dv7 series | Validity Sensor |
| dv3500t | Validity Sensor |
| EliteBook 8730w, 8530w, and 8530p | AES 2501 |
| EliteBook 6930p | AES 2501 |
| Compaq 2230s | AES 2501 |
| HP 2530p | AES 2501 |
| Touchsmart tx2z | AES 2501 |
| | |
| Toshiba | Sensor Notes |
| New Models | |
| Tecra models | Most Likely an Authentec Swipe or Upek Swipe |
| Satellite U400 | Most Likely an Authentec Swipe or Upek Swipe |
| Protégé | Most Likely an Authentec Swipe or Upek Swipe |
| 2005 | |
| Libretto U100 | AES 2500 |
| Portege R200 | AES 2500 |
| Tecra S3 M740 | AES 2501A swipe |
| Tecra S3 M780 | AES 2501A swipe |
| 2006 | |
| Portege M400 | Upek swipe |
| Tecra M7 | Upek swipe |
| Satellite R25-S3513 | Upek swipe |
| Satellite Pro P100 | Upek swipe |
| Satellite P105 series | Upek swipe |
| Tecra A6 | Upek swipe |
| Tecra A7 | Upek swipe |
| Tecra M5 | Upek swipe |
| Qosmio G35-AV600 | Upek swipe |
| G35-A660 | Upek swipe |
| G30-AV6 | Upek swipe |
| Satellite A105-S4014 | Upek swipe |
| Dynabook SS MX/395LS | Upek swipe |
| Dynabook SS MXW | Upek swipe |

| | |
|---------------------------|---------------------|
| Dynabook SS M36 | Upek swipe |
| Dynabook SS S30 | Upek swipe |
| Tecra M6 | Upek swipe |
| Satellite Pro U200-ST3311 | Upek swipe |
| Portege M500 | Upek swipe |
| Tecra A8 | Upek swipe |
| Satellite J61 | Upek swipe |
| 2007 | |
| R400 Tablet PC | Upek swipe |
| A205 Series | Upek swipe |
| A203 | Upek swipe |
| Qosmio G40/G45 | Upek swipe |
| Satellite P205 | Upek swipe |
| Qosmio PQG4097 | Upek swipe |
| Qosmio G45-AV690 | Upek swipe |
| Tecra A9/M9 | Upek swipe |
| Tecra X9 | Upek swipe |
| Tecra S5-11S &S5-11K | Upek swipe |
| Tecra M8-S8011 | Upek swipe |
| M600 | Upek swipe |
| Satellite U305 | Upek swipe |
| M601 | Upek swipe |
| M612 | Upek swipe |
| Dynabook CXJ47C | Upek swipe |
| Dynabook SS M41 | Upek swipe |
| Dynabook SS RX1 | Authentec Swipe |
| Portege R500 | Authentec Swipe |
| Portege R501 | Authentec Swipe |
| Dynabook SS RX2 | Authentec Swipe |
| Portege R600 | Authentec Swipe |
| Dynabook Satellite WXW | Upek swipe |
| M200 | Upek swipe |
| X205 | Upek swipe |
| Portege M700 Tablet PC | Authentec Swipe |
| 2008 | |
| U405 | Authentec Swipe |
| M801/M802 | Authentec Swipe |
| M803 | Authentec Swipe |
| M807 | Authentec Swipe |
| U400 | Authentec Swipe |
| Qosmio F50 and G50 | Authentec Swipe |
| Qosmio FX | Authentec Swipe |
| Qosmio X300 Series | Authentec Swipe |
| Satellite Pro S300 | Authentec Swipe |
| Tecra M10 and A10 | Authentec Swipe |
| Fujitsu | Sensor Notes |
| New Models | |

| | |
|--|--|
| S series | Restriction in disclosing Sensor Information |
| T series | Restriction in disclosing Sensor Information |
| E series | Restriction in disclosing Sensor Information |
| V series | Restriction in disclosing Sensor Information |
| 2005 | |
| P7120 and P7120B | AES 2500 |
| Stylistic ST5020 | Authentec Swipe Sensor |
| FMV-Stylistic TB11/B, TB11/S | Authentec Swipe Sensor |
| Stylistic ST5022 | Authentec Swipe Sensor |
| Stylistic ST5032 | Authentec Swipe Sensor |
| Sylistic TB12 | Authentec Swipe Sensor |
| Life Book S7010 & S7011 | Authentec Swipe Sensor |
| Life Book S7020, S7021 | Authentec Swipe Sensor |
| Lifebook S7025 | Authentec Swipe Sensor |
| Lifebook B6000 | Authentec Swipe Sensor |
| LifeBook P1500 / P1510D | Authentec Swipe Sensor |
| LifeBook FMV P8210 Tablet PC | Authentec Swipe Sensor |
| LifeBook FMV T8210 Tablet PC | Authentec Swipe Sensor |
| 2006 | |
| Stylistic ST5112 | Authentec Swipe Sensor |
| Lifebook B6210 | Authentec Swipe Sensor |
| LifeBook FMV B8230 | Authentec Swipe Sensor |
| FMV biblo Loox P70S | Authentec Swipe Sensor |
| FMV P1610 | Authentec Swipe Sensor |
| LifeBook T4210 Tablet PC | Authentec Swipe Sensor |
| T4215 | Authentec Swipe Sensor |
| Lifebook FMV E8110 | Authentec Swipe Sensor |
| LifeBook S7110 | Authentec Swipe Sensor |
| Lifebook FMV E8210-3G | Authentec Swipe Sensor |
| Lifebook S7111 | Authentec Swipe Sensor |
| LifeBook FMV E8230, H8230 | Authentec Swipe Sensor |
| S6310, S6311 | Authentec Swipe Sensor |
| LifeBook FMV Q8220, Q8230, Q8240 | Authentec Swipe Sensor |
| LifeBook FMV NX series, NB series, MG series | Authentec Swipe Sensor |
| N6420 | Authentec Swipe Sensor |
| LifeBook A3110 | Authentec Swipe Sensor |
| LifeBook A6010 & A6110 | Authentec Swipe Sensor |
| LifeBook A6230, NF70T, FN45T | Authentec Swipe Sensor |
| LifeBook FMV C6230 | Authentec Swipe Sensor |
| P7230 | Authentec Swipe Sensor |
| FMV LifeBook C6230 | Authentec Swipe Sensor |
| P7230 | Authentec Swipe Sensor |
| Fujitsu-Siemens Lifebook Q2010 | Authentec Swipe Sensor |
| 2007 | |
| Stylistic TB13 /B, /R, /S | Authentec Swipe Sensor |
| LifeBook FMV B8240 | Authentec Swipe Sensor |
| LifeBook B6220 | Authentec Swipe Sensor |
| B8250 | Authentec Swipe Sensor |
| LifeBook FMV P8230 Tablet PC | Authentec Swipe Sensor |

| | |
|--|-----------------------------------|
| P8240 | Authentec Swipe Sensor |
| FMV-T8220 | Authentec Swipe Sensor |
| T4220 | Authentec Swipe Sensor |
| T8240 | Authentec Swipe Sensor |
| E8410 | Authentec Swipe Sensor |
| E8250, H82550 | Authentec Swipe Sensor |
| LifeBook S7210 | Authentec Swipe Sensor |
| S6311K | Authentec Swipe Sensor |
| NX70Ud, NX90UD, NX95UD, NB55U/D, NB50U | Authentec Swipe Sensor |
| MG50W, MG70W | Authentec Swipe Sensor |
| N6450 | Authentec Swipe Sensor |
| NX95Y / D | Authentec Swipe Sensor |
| N6470 | Authentec Swipe Sensor |
| NF75U/V, NF70U, NF50U, NF40U/V, NF40U | Authentec Swipe Sensor |
| LifeBook FMV A6240 | Authentec Swipe Sensor |
| LifeBook A6020 & A6030 | Authentec Swipe Sensor |
| A3130 | Authentec Swipe Sensor |
| LifeBook A6110 | Authentec Swipe Sensor |
| NF75Y, NF50Y | Authentec Swipe Sensor |
| C6240 | Authentec Swipe Sensor |
| Loox T70X | Authentec Swipe Sensor |
| LifeBook FMV C6240 | Authentec Swipe Sensor |
| S2210 | Authentec Swipe Sensor |
| UMPC FMV-U8240 | Authentec Swipe Sensor |
| FMV-BIBLO LOOX U50WN / Lifebook U1010 | Authentec Swipe Sensor |
| Loox UX50X/V | Authentec Swipe Sensor |
| Tablet PC T8140 | Authentec Swipe Sensor |
| T2010 | Authentec Swipe Sensor |
| Loox R70Y | Authentec Swipe Sensor |
| Fujitsu-Siemens S6410 | Authentec Swipe Sensor |
| S6510 | Authentec Swipe Sensor |
| MG90Y / V | Authentec Swipe Sensor |
| 2008 | |
| P1620 | Authentec Swipe Sensor |
| P1630 | unknown |
| LifeBook S7220 | Authentec Swipe Sensor |
| NF/A75D, NX/A90 | Authentec Swipe Sensor |
| A6210 | Authentec Swipe Sensor |
| U820 | Authentec Swipe Sensor |
| T2020 | Authentec Swipe Sensor |
| Loox R A70 | Authentec Swipe Sensor |
| LifeBook P8010 | Authentec Swipe Sensor |
| LifeBook P8020 | Authentec Swipe Sensor |
| LifeBook FMV-R8250 | Authentec Swipe Sensor |
| LifeBook T5010 | Authentec 1710 fingerprint sensor |
| LifeBook U2010 | Authentec 1710 fingerprint sensor |
| LifeBook E8420 | Authentec 1710 fingerprint sensor |
| L1010 | Authentec 1710 fingerprint sensor |
| LifeBook A6220 | Authentec 1710 fingerprint sensor |

| | |
|-------------------------------|-----------------------------------|
| Lifebook N7010 | Authentec 1710 fingerprint sensor |
| MV-BibloS/C50 | Authentec 1710 fingerprint sensor |
| FMV Biblio NW series | Authentec 1710 fingerprint sensor |
| MG/A75, MG/A50 | Authentec Swipe Sensor |
| S6520 | Authentec Swipe Sensor |
| Stylistic ST6012 Tablet PC | Authentec Swipe Sensor |
| Esprimo series | Authentec 2550 sensor |
| Esprimo U9210, U9410 | Authentec 2550 sensor |
| IBM / Lenovo | |
| New Models | Sensor Notes |
| ThinkPad SL400 | Unknown |
| ThinkPad SL500 | Unknown |
| ThinkPad R400 | Unknown |
| ThinkPad R500 | Unknown |
| ThinkPad T400 | Unknown |
| ThinkPad T500 | Unknown |
| ThinkPad X200 | Unknown |
| ThinkPad X200S | Unknown |
| ThinkPad X301 | Unknown |
| ThinkPad X Series Tablet | Unknown |
| ThinkPad W500 | Unknown |
| ThinkPad W700 | Unknown |
| 2005 | |
| ThinkPad T43 | TouchStrip from Upek |
| ThinkPad R52 | TouchStrip from Upek |
| ThinkPad X41 | TouchStrip from Upek |
| Thinkpad Z60m & Z60t | TouchStrip from Upek |
| Lenovo E660 | TouchStrip from Upek |
| 2006 | |
| Thinkpad x60 | TouchStrip from Upek |
| Thinkpad Z60m & Z60t | TouchStrip from Upek |
| Thinkpad Z61m & Z61t | TouchStrip from Upek |
| ThinkPad Z61P | TouchStrip from Upek |
| Lenovo E680 | TouchStrip from Upek |
| Lenovo E680A | TouchStrip from Upek |
| Thinkpad T60p | TouchStrip from Upek |
| Lenovo Thinkpad R60. | TouchStrip from Upek |
| Lenovo Thinkpad T60 | TouchStrip from Upek |
| Lenovo 3000 N100 | Authentec Swipe Sensor |
| Lenovo 3000 C200 | Authentec Swipe Sensor |
| Lenovo 3000 V100 | Authentec Swipe Sensor |
| Lenovo E390 | Authentec 1510 swipe sensor |
| 2007 | |
| Thinkpad X61 / X61S Tablet PC | TouchStrip from Upek |
| Lenovo Thinkpad R61 | TouchStrip from Upek |
| Thinkpad T61 | TouchStrip from Upek |
| ThinkPad T61p | TouchStrip from Upek |

| | |
|---------------------------------------|------------------------------|
| Lenovo 3000 N200 | Authentec Swipe Sensor |
| Lenovo 3000 V200 | Authentec Swipe Sensor |
| Lenovo N440 | Authentec Swipe Sensor |
| E390A | Authentec 1510 swipe sensor |
| X61 / X61S | TouchStrip from Upek |
| K42 | TouchStrip from Upek |
| 2008 | |
| X300 | TouchStrip from Upek |
| X301 | TouchStrip from Upek |
| X200 | TouchStrip from Upek |
| W700 | Authentec swipe Sensor |
| SL300, SL400 & SL500 | TouchStrip from Upek |
| X200t tablet PC | Authentec Fingerprint Reader |
| E23 notebook | Authentec Fingerprint Reader |
| Sony | Sensor Notes |
| New Models | |
| 13" Z series | Unknown |
| 11" TT series | Unknown |
| 2005 | |
| Vaio BX Series | UPEK Swipe Sensor |
| BX143C, BX145CP, BX178CP | UPEK Swipe Sensor |
| Vaio AX series | UPEK Swipe Sensor |
| 2006 | |
| BX245 | UPEK Swipe Sensor |
| Vaio SZ Series | UPEK Swipe Sensor |
| VGN-SZ18GP | UPEK Swipe Sensor |
| VAIO® VGN-SZ91 and -SZ81 | UPEK Swipe Sensor |
| VAIO SZ2VP / SZ240 | UPEK Swipe Sensor |
| Vaio VGN-SZ82 | UPEK Swipe Sensor |
| Vaio SZ3 series (VGN-SZ32CP) | UPEK Swipe Sensor |
| VAIO® UX Micro PC (UMPC) VGN-UX50/90 | UPEK Swipe Sensor |
| aio VGN TX800 | UPEK Swipe Sensor |
| VGN-TXN10 & VGN-TXN15 | UPEK Swipe Sensor |
| VGN-TX37CP / VGN-TX45LP | UPEK Swipe Sensor |
| VGN-G1LAP & VGN-G1KAP | UPEK Swipe Sensor |
| 2007 | |
| BX40s | UPEK Swipe Sensor |
| BX345 | UPEK Swipe Sensor |
| Vaio VGN-SZ37CP | UPEK Swipe Sensor |
| SZ422 / SZ432 / SZ452 | UPEK Swipe Sensor |
| SZ6 | UPEK Swipe Sensor |
| VAIO® VGN-SZ94 and -SZ84 | UPEK Swipe Sensor |
| VGN-SZ54B/B & VGN-SZ74B/B, SZ55, SZ56 | UPEK TCS4 |
| SZ58 | UPEK TCS4 |
| UX1XN | UPEK Swipe Sensor |
| VGN-UX390N | UPEK Swipe Sensor |
| UX50 | UPEK Swipe Sensor |

| | |
|-----------------------------|---------------------|
| UX37 | UPEK Swipe Sensor |
| UX72 | UPEK Swipe Sensor |
| VGN-UX490N, VGN-UX92 | UPEK Swipe Sensor |
| GN-TXN17 | UPEK Swipe Sensor |
| TX5 | UPEK Swipe Sensor |
| VGN-TX47GP/B | UPEK Swipe Sensor |
| VGN-G11 | UPEK Swipe Sensor |
| VGN-G118CN/T | UPEK Swipe Sensor |
| G2 | UPEK Swipe Sensor |
| VGN-TZ50B | UPEK Swipe Sensor |
| TZ90S, TZ11 | UPEK Swipe Sensor |
| TZ17, TZ150N | UPEK Swipe Sensor |
| TZ12 | UPEK Swipe Sensor |
| TZ13 | UPEK Swipe Sensor |
| VGN-TZ71/B | UPEK Swipe Sensor |
| TZ26, TZ27 & TZ28 | UPEK Swipe Sensor |
| GN-CR15 | UPEK Swipe Sensor |
| 2008 | |
| SZ75, SZ76 | UPEK TCS4 |
| SZ650 | UPEK TCS4 |
| G3 | Upek Swipe Sensor |
| TZ298/N, TZ72B | Upek Swipe Sensor |
| TZ33 | Upek Swipe Sensor |
| CR31 | Upek Swipe Sensor |
| SR11 and SR19 | Upek Swipe Sensor |
| SR16 | Upek Swipe Sensor |
| BZ11 | Upek Swipe Sensor |
| Z11 | Upek Swipe Sensor |
| Z12 & Z13 | Upek Swipe Sensor |
| VAIO VGN-Z598U | Upek Swipe Sensor |
| TT160 & TT198 | Upek Swipe Sensor |
| AW180 & AW11 | Upek Swipe Sensor |
| 2009 | |
| G3 | Upek Swipe Sensor |
| SR39 | Upek Swipe Sensor |
| BZ13 | Upek Swipe Sensor |
| Z21ZN | Upek Swipe Sensor |
| TT17GN | Upek Swipe Sensor |
| TT11WN | Upek Swipe Sensor |
| TT21JN, TT21WN | Upek Swipe Sensor |
| TT250N/B | Upek Swipe Sensor |
| ACER | Sensor Notes |
| 2005 | |
| TravelMate C200 (TMC204Tmi) | Upek Swipe Sensor |
| 2006 | |
| C210 | Upek Swipe Sensor |
| TravelMate 6460 series | Upek Swipe Sensor |

| 2007 | |
|-------------------------------|------------------------------|
| TravelMate 6463, 6465WLMi | Upek Swipe Sensor |
| TravelMate Profile series | Authentec 1610 swipe sensor |
| TravelMate 6292 | Upek TCS4 swipe sensor |
| TravelMate 6492 & 6592 | Upek TCS4 swipe sensor |
| TravelMate 7720G | Upek TCS4 swipe sensor |
| TravelMate 4720 | Authentec 1610 swipe sensor |
| Ferrari 1100 | Upek TCS4 swipe sensor |
| 2008 | |
| TravelMate 7730 / 6493 & 6593 | Upek TCS4 swipe sensor |
| TravelMate 5520G | Authentec 1610 swipe sensor |
| TravelMate 5720 | Authentec 1610 swipe sensor |
| TravelMate 5730 | Authentec 1610 swipe sensor |
| Aspire 6920g & 8920g | Validity VFS201 swipe sensor |
| Aspire 8930G | Validity VFS201 swipe sensor |
| Aspire 5530 | Authentec 1610 swipe sensor |
| Aspire 4925 | Authentec 1610 swipe sensor |
| Aspire 2930 | Authentec 1610 swipe sensor |
| TravelMate 6293 | EgisTec SS801U swipe sensor |
| 2009 | |
| Ferrari 1200 | Upek TCS4 swipe sensor |
| Aspire 6930G-BC32 | Upek TCS4 swipe sensor |
| Aspire 8935G | unknown swipe sensor |
| Aspire 3935 | unknown swipe sensor |
| Asus | |
| Sensor Notes | |
| New Models | |
| N10J | Authentec biometric reader |
| U2E | Authentec biometric reader |
| N20A | Authentec biometric reader |
| U6VC | Authentec biometric reader |
| VX3 | Authentec biometric reader |
| F6VE | Authentec biometric reader |
| N81VP | Authentec biometric reader |
| M51A | Authentec biometric reader |
| N51VF | Authentec biometric reader |
| M70VM | Authentec biometric reader |
| W90VP | Authentec biometric reader |
| 2006 | |
| Tablet PC R1F | Upek swipe sensor |
| Ultra Mobile PC / Origami R2H | Authentec 1610 sensor |
| F2J Notebook | Authentec 1610 sensor |
| V1J Notebook | Upek swipe sensor |
| V2 | Authentec 1610 sensor |
| F9F notebook | Authentec 1610 sensor |
| 2007 | |
| R1E | Upek swipe sensor |
| R2E | Authentec 1610 sensor |

| | |
|------------------------------------|------------------------------|
| F2W55F-SL | Authentec 1610 sensor |
| V2S | Authentec 1610 sensor |
| Sting 414 | Authentec 1610 sensor |
| F9J | Authentec 1610 sensor |
| F9G | Authentec 1610 sensor |
| U1F | Authentec 1610 sensor |
| U1E | Authentec 1610 sensor |
| Lamborghini VX2 | Authentec 1610 sensor |
| VX2S Lamborghini | Authentec 1610 sensor |
| Rugged Military NB | Upek swipe sensor |
| Z37S | Upek swipe sensor |
| Multicom Z37S | Upek swipe sensor |
| Portable One SXS37 | Upek swipe sensor |
| Rizeon Z37S | Upek swipe sensor |
| C90 | Upek swipe sensor |
| Livebook Diablo | Upek swipe sensor |
| Velocity Micro NoteMagix C90 Ultra | Upek swipe sensor |
| F3sv-A1 | Authentec Fingerprint Sensor |
| F8S | Authentec Fingerprint Sensor |
| F8 Infusion series | Authentec Fingerprint Sensor |
| U3 | Authentec Fingerprint Sensor |
| R3 UMPC | Authentec Fingerprint Sensor |
| U6 | Authentec Fingerprint Sensor |
| F8P | Authentec Fingerprint Sensor |
| 2008 | |
| VX3 | Authentec 1610 sensor |
| Z37K | Upek Swipe sensor |
| Salo S3150 / S3170 | Upek Swipe sensor |
| Rock Pegasus 520 | Upek Swipe sensor |
| C90P | Upek Swipe sensor |
| F8M & F8H | Authentec Fingerprint Sensor |
| U3K725 | Authentec Fingerprint Sensor |
| R50 | Authentec Fingerprint Sensor |
| U6Ep | Authentec Fingerprint Sensor |
| U6V | Authentec Fingerprint Sensor |
| M50S & M70S | Authentec Fingerprint Sensor |
| M51 | Authentec Fingerprint Sensor |
| M51Va | Authentec Fingerprint Sensor |
| F6K54E-SL | Authentec Fingerprint Sensor |
| U2E | Authentec Fingerprint Sensor |
| R70 UMPC | Authentec Fingerprint Sensor |
| X55Sr | Authentec Fingerprint Sensor |
| F80S | Upek Swipe Sensor |
| N10 / N10J | Upek Swipe Sensor |
| B50A | Authentec Swipe Sensor |
| B80A | Authentec Swipe Sensor |
| L50V | Authentec Swipe Sensor |
| N80Vn-A1 | Authentec Swipe Sensor |
| 2009 | |

| | |
|--------------------------------|-----------------------------|
| N20A | Upek Swipe Sensor |
| M90GF | Upek Swipe Sensor |
| W90Vn, W90Vp | Upek Swipe Sensor |
| P30 | Egistec SS501 sensor |
| P90 | Egistec SS501 sensor |
| Eee PC 1004DN | Authentec 1610 Sensor |
| Samsung | |
| 2001 | Sensor Notes |
| GT9000/Sense 950 | UPEK TCS1 |
| 2002 | |
| T10 | UPEK TCS1 |
| P10 | UPEK TCS1 |
| 2003 | |
| P20. | UPEK TCS1 |
| P30 | UPEK TCS1 |
| X10 | Authentec Touch Sensor |
| X05 | Authentec Touch Sensor |
| X15 | Authentec Touch Sensor |
| X30 | Authentec Touch Sensor |
| M30 | Authentec Touch Sensor |
| V30 | Authentec Touch Sensor |
| 2004 | |
| P35 | UPEK TCS1 |
| X10+, X15+ | Authentec Touch Sensor |
| 2005 | |
| P40 | Upek Fingerprint Sensor |
| X25, X50 | Authentec Touch Sensor |
| X06 | Authentec Touch Sensor |
| 2007 | |
| Q1 Ultra UMPC | Authentec 1610 swipe sensor |
| Q1U-SSDXP, Q1U-ELXP and Q1U-XP | Authentec 1610 swipe sensor |
| 2008 | |
| Q1 Ultra Premium | Authentec 1610 swipe sensor |
| X360 | Authentec Swipe Sensor |
| X460 | Authentec Swipe Sensor |
| P460/P560 | Authentec Swipe Sensor |
| Gateway | |
| 2004 | Sensor Notes |
| 450XL | Upek TouchStrip TCS3 |
| 2007 | |
| E-155C tablet PC | Upek TouchStrip |
| C120X | Upek TouchStrip |
| S-7125C | Upek TouchStrip |
| E-295C & C-140X | Upek TouchStrip |
| C-5817c | Upek TouchStrip |
| E-295C & C-140X QS | Upek TouchStrip |

| | |
|-------------------------|-------------------------|
| E-265M & E-475M | Upek Fingerprint Sensor |
| T-6815 / M-6816 series | UPEK TouchStrip |
| M-150X and T-140X | UPEK TouchStrip |
| T-6821c | UPEK TouchStrip |
| M-150XL | UPEK TouchStrip |
| 2008 | |
| M-151X & M-151XL | UPEK TouchStrip |
| M-152X | UPEK TouchStrip |
| P-171XL FX | UPEK TouchStrip |
| P-7811 FX | UPEK TouchStrip |
| LG | Sensor Notes |
| New Models | |
| 2006 | |
| M1 | Authentec Swipe |
| P1 | Authentec Swipe |
| T1 | Authentec Swipe |
| S1 | Authentec Swipe |
| M1-J255R | Authentec Swipe |
| M1-52A6A | Authentec Swipe |
| 2007 | |
| R400 | Authentec Swipe |
| R500 | Authentec Swipe |
| Panasonic | Sensor Notes |
| New Models | |
| H1 52 | Unknown |
| H1 30 | Unknown |
| 2006 | |
| ToughBook CF-74 | Upek Swipe Sensor |
| ToughBook CF-Y5 | Upek Swipe Sensor |
| ToughBook CF-19 & CF-30 | Upek Swipe Sensor |
| 2007 | |
| Y7 | Upek Swipe Sensor |
| ToughBook CF-52 | Upek Swipe Sensor |
| 2008 | |
| W7 | Upek Swipe Sensor |
| ToughBook CF-U1 | Upek Swipe Sensor |
| Toughbook F8 | Upek Swipe Sensor |
| ToughBook T8 | Upek Swipe Sensor |
| ToughBook W8 | Upek Swipe Sensor |
| ToughBook MCA | Upek Swipe Sensor |
| ToughBook CF-H1 | Upek Swipe Sensor |